

apply general construction adhesive on capital

capital

install with column ring at top

drill 4 holes thru cap fasten with screw patch hole

column

drill 4 holes into base 1/2" dia from far side drill holes into floor the same location as base, place pins into floor with epoxy glue, fill holes in base also with epoxy, then position base over pins in floor.

base

floor

apply general construction adhesive on base

3/8 dia locator pin

